How-to interpret the Tezro LED information

Published 11/05/2003

Symptom(s):

How-to interpret the Tezro LED information

Fact(s):

SGI Tezro
Bezel LED Signals
LED information

SGI Solution:

LED meaning is:
Blinking White
Power button pressed (On or Off)

Solid white
Successful PROM boot/ OS running

Solid yellow
L1 has detected a problem. Check the L1 display for more information

Blinking red
General system failure
Check the L1 display for more information

Solid red
System node board failure
(failed to read PROM at power on)

Answers others found helpful

- Silicon Graphics Tezro
- Cannot boot miniroot
- Amber LED on front of SGI Origin 200 flashing.
- System LED value (check output of the 'leds' command from the L1 and L2 pompt) reflects 0x90 (FLED_MAX_APPWT)

Additional Details

Creation Date	11/05/2003 11:18 AM
Last modification	10/31/2016 09:01 PM
Published Date	11/05/2003
Products	• Servers and Clusters • SGI Origin/Onyx • Origin/Onyx Server • Workstations • SGI Tezro
Categories	• Knowledgebase • Technical Solution